

# **Quick Start Guide**

## EFace10

Version: 1.1

Due to regular upgrades of systems and products, ZKTeco could not guarantee exact consistency between the actual product and the written information in this manual.

## Overview



Note: Features and parameters with ★ mark are not available in all devices.

## **Installation Environment**

Please refer to the following recommendations for installation.



INSTALL INDOORS ONLY



AVOID INSTALLATION NEAR GLASS WINDOWS



AVOID DIRECT SUNLIGHT AND EXPOSURE



AVOID USE OF ANY HEAT SOURCE NEAR THE DEVICE

## **Recommended Standing Position**



KEEP EFFECTIVE DISTANCE OF 0.3-2m

# **Standalone Installation**



## **Power Connection**



#### **Recommended AC Adapter**

- 1) 12V ± 10%, at least 1500mA.
- 2) To share the power with other devices, use an AC Adapter with higher current ratings.

## **Ethernet Connection**

Connect the device and computer software over an Ethernet cable. As shown in the example below:



Click on [COMM.] > [Ethernet] > [IP Address], input the IP address and click on [OK].

Note: In LAN, the IP addresses of the server (PC) and the device must be in the same network segment when connecting to the **ZKBioAccess IVS** software.

## **Lock Relay Connection**

The system supports **Normally Opened Lock** and **Normally Closed Lock**. The **NO Lock** (normally opened when powered) is connected with '**NO**' and '**COM**' terminals, and the **NC Lock** (normally closed when powered) is connected with '**NC**' and '**COM**' terminals. An example with NC lock is shown below:

## Device not sharing power with the lock



## Door Sensor, Exit Button & Auxiliary Input Connection



**Note:** Backup rechargeable battery: Offers at least 2 hours of power on a full charge, and it takes 4 hours to recharge.

## **User Registration**

When there is no super administrator set in the device, click on  $\equiv$  to enter the menu. Add a new user and set User Role to Super Admin, then the system requests for the administrator's verification before entering the menu. It is recommended to register a super administrator initially for security purposes.

#### Method 1: Registering on the device

Click on  $\equiv$  > [User Mgt.] > [New User] to register a new user. The options include entering the user ID and Name, setting User Role and Verification Mode, registering Face, Card Number  $\bigstar$ , Password, and adding User Photo.





Ð	User Mgt.	
👱 New User		
🗾 All Users 💟		
🜔 Display Style		

Ð	New User	11
User ID		3
Name		
User Role		Normal User
Verification Mode		Password/Card/Face
Face		0
Card Number		





## Method 2: Register on ZKBioAccess IVS software

Please set the IP address and cloud service server address in the Comm. Menu option on the device.

1. Click [Attendance] > [Attendance Device] > [Device] > [Search] to search the device on the software. When an appropriate server address and port is set on the device, the searched devices are displayed automatically.



- 2. Click [Add] in operation column, a new window will pop-up. Select Attendance Area and Time zone from each dropdowns and click [OK] to add the device.
- Click [Personnel] > [Person] > [New] and fill in all the required fields to register a new users in the software.
- Click [Attendance Device] > [Device] > [Control] > [Synchronize Software Data to the Device] tosynchronize all the data to the device including the new users.

For more details, please refer to the ZKBioAccess IVS User Manual.

### Method 3: Register on the phone

Once the ZKBioAccess IVS software is installed, the users could enroll their face via a browser application on their own mobile phone.

 Click [Personnel] > [Parameters], input "http://Server address: Port" in the QR Code UGL bar. The software will automatically generate a QR code. Scan the QR code or login onto "http://Server address: Port/app/v1/adreg" by the mobile phone to register users.



 The users will be displayed in [Personnel] > [Pending Review], click on [Review] option and assign a department and click [OK] to successfully add the user.

	ZKTECO	8	8 0	0	ß	@ @						\varTheta admin ~
		Pas	CI lerroi		Nar	90	Q 🛞					
٠		The c	utions query co	nditions None								
		0.5	iehesh 🔐 De	iete								
			Personnel ID	First Name		Last Name	Mobile Phone		Status	Create Time	Operations	
			1190130	mka			******		Pending review	2021-03-10 14:47:12	Basing Dalate	
					_		Review		×			
					Person							
						-	Personnel ID	1190130	_			
							First Name	nika				
						1	L and Marrie					
						-	Casi marite		_			
						and the second second	Mobile Phone	11111111	н			
						Photo						
						0	Cancel					
					4				•			
_												
	Card Management			<ul> <li>&gt;1 60</li> </ul>	) rows per pa	ge - Jump To 1	/I Page Total of 1	records				

# **Ethernet and Cloud Server Settings**

Click on  $\equiv$  > [COMM.] > [Ethernet] to set the network parameters. If the TCP/IP communication of the device is successful, the icon  $\square$  will be displayed in the upper right corner of the standby interface.

Click on  $\equiv$  > [COMM.] > [Cloud Server Setting] to set the server address and server port, that is, the IP address and port number of the server after the software is installed. If the device communicates with the server successfully, the icon will be displayed in the upper right corner of the standby interface.



5	Ethernet 11	5	Cloud Server Setting	11
IP Address	192.168.163.99	Server Mod	le	ADIv
Subnet Mask	255.255.255.0	Enable Dom	nain Name	
Gateway	192.168.163.1	Server Add	ress	0.0.0
DNS	0.0.0.0	Server Port		808
TCP COMM.Port	4370	Enable Prox	cy Server	
DHCP	0	HTTPS		0

#### Note:

While pairing the device with ZKBioAccess IVS software. Make sure that the option **Enable Domain Name** is disabled and the correct server address and port are entered. **Server Address:** Set as the IP address of the ZKBioAccess IVS server.

Server Port: Set as the service port of ZKBioAccess IVS.

## **Access Control Setting**

Click on  $\equiv$  > [Access Control] to enter the access control management interface and set relevant parameters of access control.



Access Cor	tral Options
	10
s)	10
	Normal Close (NC)
	Access Cor (s)

## **Attendance Record**

Click on  $(\equiv) > [Attendance] > [Attendance Record]$  to enter the record query interface, input the user ID and select the time range, the corresponding attendance record will be displayed.



Ð	Attendance Search
E Attenda	ance Record
🚺 Attenda	ance Photo
Blocklis	st ATT Photo

5	User ID					
	Please Input(query all data without input)					
1	2	3	$\times$			
4	5	6	^			
7	8	9	$\sim$			
ESC	0	123	ОК			

∍	Personal Record Search				
Date	User ID	Time			
01-25		Number of Records:04			
	2	09:58 09:53 09:51 09:48			
01-22		Number of Records:09			
	1	16:17 16:01 15:57			
	2	16:17 16:09 16:02 16:01 15:58			
		15:57			

www.zkteco.eu

Copyright © 2022 ZKTECO CO., LTD. All Rights Reserved.