User Manual

WIFI Access Control

Version: 1.0

Due to the regular upgrades of systems and products, We could not guarantee exact consistency between the actual product and the written information in this manual.

1 Introduction

This device is a WiFi based Touch Key Access Controller & RFID Reader. User can install the mobile app (ZSmart) to easily access the door with their mobile phones. The app supports up to 500 mobile users, and can manage a maximum of 1000 users (Figerprint/PIN/Card) through the app.

2 APP Operation

Here are just a few steps to get you started.

1) Free APP Downloading

Search ZSmart on Google Play or APP Strore.







2) Make sure WiFi works on your mobile phone.

3 Register and Login

Make sure the registered email is legal and valid, so that you can recover your password if forgotten.



You will get a verification code in your mailbox.

4 Add Device

Click [Add Device] or
 eicon on the Home interface to add a new decive.

Note: It is suggested to turn on the Bluetooth, as it makes it easier to find and add the device more quickly.

- 2. Add the scanned device, and input the WiFi password.
- 3. After the device is successfully added, data is automatically synchronized.



Note: To better manage the devices and family members, you will need to create a home before you begin to manage the device.

Click [Me] > [Home Management] > [Create a home] to create a home.



5 Authority

Note: The first account to add the device is home owner.

Authority	Home Owner (Super Master)	Administrator	Ordinary Member	
Open the Door	0	0	0	
Member Management	0	0	×	
User Management	0	0	×	
Set Users as Admin	0	×	×	
View All Records	0	0	×	
Set Relay Time	0	0	×	

6 User Management

6.1 Add Members

- 1. Click the device on the Home interface to enter the manage interface.
- 2. Click [Member manage].
- 3. Click [+] on the upper right corner of the interface to add a new member.



Note: When adding members, the Owner (Super Master) can decide to add the user as Administrator or ordinary member.

6.2 Manage Members

Owner (Super Master) can decide effective time (Permanent or Limited) of the members.

- 1. Choose a member and click on the Member interface.
- 2. Click [Effective time].
- 3. Choose "Customize", and then you can set the effective date and time.



6.3 Delete Members

- 1. Choose a member and click on the Member interface.
- Click [Delete user] on the upper right corner of the interface to delete this member.

<	Member	+
Q us Ad	er Name/account Iministrator Ordinary r	nember
C	Ordinary member "dissnant.com © 0 © 0 □	0
Q	2 Terrator	

6.4 Add Fingerprint/Code/Card Users

You can add or delete fingerprint, code, and card for the users.

- 1. Choose a member and click on the Member interface.
- 2. Click [+Add], and then add fingerprints/code/card as instructed.
- Click a fingerprint (code/card) to enter the manage interface, click [Delete Fingerprint] ([Delete Code]/[Delete Card]) to delete.

< Member +	<	Cancel Add fingerprint
User Nernehasseurit Administrator Ordinary member Ordinary member Namenter	Ordinary member *Across Caro	
C 2 C C C C C C C C C C C C C C C C C C	Frogenet Marging Aust	2: Les dans the processor
	Code Passwordfol Add Covet	
Cancel Save How to add code Passes save the code in time, Age will no longer displayed	Cancel Add card	Cancel Edit Save
Peer rep i Agint cole Ingla cole Cole same Peer rep a series Peer	(). Are used and the set of the set of the decision of the set of the decision of the set of the set of the set of the set of the decision of the set of t	

Simplified Instruction



7 Temporary Code

The temporary code can be shared to the guest by SNS tools (such as Whatsapp, Skype, Wechat and so on). There are two types of it.

Cyclicity

- 1. Click the device on the Home interface to enter the manage interface.
- 2. Click [Temporary code].
- Select "Cyclicity", input the temporary code and set the date and time, and click [Save].
- 4. Click [Share] to share the code, and click [Done] to finish.

0	< WIFI Access Control	∠ Add temporary co… Log rec…
All Devices		Code type Oyclicity Once
WIFI Access Control	A	Please input 6 sligitati code
		987654 Randomly generated
		Copy
	Access control1 Z	Effective date 2023/06/07 14:34 >
		Expiry date 2023/06/23 14:34 >
	٠	Repeat C
	No data	Start time 08:00 >
	Member manage	> End time 2000 >
	Temporary code	San War Tay Wed Tay Pel Sat
a 9 8	Setting	Save
Hyre Sopre Ma		
Add temporary com Log recm	Add temporary co Log res	
987654	987654	
Code name cyclicity	Code name oyd	19.
Invalid time 2023/06/23 14:34	Invalid time 2023/06/23 5	
Repeat Every Mon. Tue. Wes. Thu, Fri DB 00-2000	Repeat Every Mon. Tax. Wes. Tru- 05 00-2	
Done	Dana	
Store	Store	
	Email Message Copy	
	More	
	Cancel	

Once

- Select "Once", and click [Save offline code], then the system automatically generates a random code, which is valid for six hours and can only be used once.
- 2. Click [Share] to share the code, and click [Done] to finish.



7.1 Edit/Delete Temporary Code

- 1. Click [Log record] on the upper right of add interface.
- 2. Choose the code to be edited and click.
- 3. Click [Edit] to edit the code, click [Delete] to delete this code.



8 Setting

- 1. Click the device on the Home interface to enter the manage interface.
- 2. Click [Setting].

٢	•	<	WIFI Access Control	<	< Set	ing
All Devices					Remote unlock setting	
					Automatic lock	
WIFI Access Cont	rol				Auto lock time	
			Press States		Alarm time	11
					Key volume	Key volume
			Access centrell Z			
			Closed			
		•	No data			
		8	Member manage	->		
		0	Temporary code	->		
		0	Setting	>		
<u>a</u> 🖸	ê					

Remote unlock setting:

Default is off. When added the device for the first time, it will prompt you to turn it on. Once it is turn off, all the mobile users will not be able to access the lock by app.

Automatic lock:

Default is on. When it is on, the lock operates in pulse mode. When it is off, the lock switches to latch mode.

Auto lock time:

Default is 5 seconds. It can be set from 0 to 100 seconds.

Alarm time:

Default is 3 minutes. It can be set from 1 to 3 minutes.

Key volume:

It can set key volume mute, low, middle and high.

9 Log

- 1. Click the device on the Home interface to enter the manage interface.
- 2. Click Log icon 🥥 to view the open history and alarms.



10 Remove Device & Reset Bluetooth Binding

- 1. Click the device on the Home interface to enter the manage interface.
- 2. Click 🖊 on the upper right of the manage interface.
- 3. Click [Remove Device].

0	•	WIFI Access Control	<	<
				Device Information
All Devices		-		Tap-to-Run and Automation
IN WELACCESS Control				Third-party Control
				0
		Press Is unlock		Aissa
				Device Offline Notification
		Access control1 2		Offline Notification
				Oters
				Share Device
				Create Group
		No data		FAQ & Feedback
	•	Member manage	>	Add to home screen
		Temporary code	,	Check Device Network Check Now >
		Setting	,	Device Update No updates available >
A Come de la				Remove Device



Note:

- Disconnect is just removing the device from the APP. The users' informations (such as fingerprint, code, card) are still retained. (If Owner disconnected, all other members will not be able to access the device.)
- Disconnect and wipe data is unbinding the device and reset Bluetooth, which means the device can be connected by other new users.

Reset the Bluetooth on the Device

Press * \rightarrow Master Code (default is 123456) \rightarrow # \rightarrow 9 \rightarrow Master Code \rightarrow #. Note: For more information, please refer to the relevant user manual.

* All the verification mode in this manual are for reference only, please refer to the actual purchase.

